

HD PROFESSIONAL

BUR2 15Li HD - 146027; BUR2 18Li HD - 142702

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
	1	360582 Screw M6LHX30-8.8		15	142686 Spring
	2	148015 Drill Chuck SG130		16	142685 Lock button
	3	146006 Gear box ass'y I_55,44/11,09 /BSP001N 2DDH		17	142681 Bracket
	4	146011 Change Knob Set		18	361358 Screw J2-M4x8-8.8
	5	146010 Spring		19	361414 Bolt D2 M8x85
	6	146007 Spring		20	142662 Console
	7	361358 Screw J2-M4x8-8.8		21	142661 Base of handle
(1)	8	148336 DC motor sub Ass'y 14.4V	(1)	22	360173 Nut M8
(2)	8	148453 DC motor sub Ass'y 18V+Pinon	(1)	23	148365 Battery pack ass'y BL 1440
	9	142692 Casing set	(2)	23	148363 Battery pack ass'y BL 1840
	10	361303 Screw		24	148367 Charger.ass'y/EU (12-18V/1,5-3Ah)Li
	11	142684 Reverse knob		201	143638 Operating instruction
(1)	12	146002 PCB+switch BR2 15Li HD		202	143588 Tool case
(2)	12	146003 PCB+switch BR2 18Li HD			
	13	148362 Screen BUR2 15/18Li HD			
	14	360149 Nut M4			

Note:

(1) - only for BUR2 15Li HD; (2) - only for BUR2 18Li HD

BUR2 15Li HD BUR2 18Li HD

