

PROFESSIONAL

BR2 12E - 186810; 186966

POS. No.	Ref.No.	Description
	1	186911 Chuck screw /BR2 12E
	2	186912 Chuck/BR2 12E
	3	186817 Torque sleeve/BR2 12E
	4	186834 Torque spring/BR2 12E
	5	186818 Gear box ass'y/BR2 12E
	6	186819 SHIFT BUTTON/BR2 12E
(1)	7	186913 Pinion/BR2 12E
(2)	7	186967 Pinion/BR2 12E
(1)	8	186816 Motor /BR2 12E
(2)	8	186968 Motor /BR2 12E
	9	186814 Reverse button/ BR2 12E
	10	186915 PCB&Switch ass'y/BR2 12E
	11	186916 Screw/BR2 12E

POS. No.	Ref.No.	Description
	12	186813 Led cap/BR2 12E
	13	186812 Housing (R&L) ass'y/BR2 12E
	14	181794 Battery set BR 12E/ 1,5Ah
	14	182159 Battery set BR 12E 1,7Ah
	14	182160 Battery set BR 12E 2Ah
	15	181795 Charger EU BR 12E 1,5Ah
	15	183178 Charger EU BR 12E 1,7Ah
	15	183187 Charger EU BR 12E 2Ah
	15	181796 Charger GB BR 12E 1,5Ah
	15	183183 Charger UK BR 12E 1,7Ah
	15	183188 Charger UK BR 12E 2Ah

Note:
 (1) - only for BR2 12E-186810; (2) - only for BR2 12E-186966

BR2 12E

