

**PROFESSIONAL, HD PROFESSIONAL**

**MB 2200P (from 01.02.2010) - 178758; MB 2200PA - 156423; MB 2200 (from 01.02.2010) - 178757  
 MB 2200PA/AVR - 156423; MB 2200P HD - 158762; MB 2200PA HD - 158772**

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
(1)(2) (3)(4) (5)(6)	1	178878 Gear box	(3)	39	170668 Switch PS16E01
	1	158701 Gear box HD	40	361328	Screw K4x18 TORX 20
	2	330125 Bearing HK 1212	41	151671	Cord clamp
	3	330944 Bearing 6300 2RSL P63 LDS18SpA	42	361360	Screw K 4X9.5 TORX 20
	4	153341 Gasket	43	361371	Screw K5X40(D10) TORX 20
	5	173936 Inner Flange	44	120724	Cord protector
	6	173934 Circlip	(1)(2) (3)(4) (5)(6)	45	152574 Cord with a plug
	7	174022 Spindle		45	158695 Cord with a plug euro plug RAL 3020
	8	173935 Rubber bush	46	361369	Screw A-K 5x25 TORX 20
(1)(2) (3)(4) (5)(6)	9*	177360 Bearing bed	47	121837	Back up disc washer
	9**	142598 Bearing bed	48	121838	Locking nut
	9*	158713 Bearing bed HD	49	178768	Guard Φ180 T20
(1)(2) (3)(4) (5)(6)	9**	142270 Bearing bed HD	(1)(2) (3)(4) (5)(6)	49	158854 Guard Φ180 T20/HD
	10	117504 Spacer washer	50	154269	Special spanner 240
	11	117505 Spacer washer	(1)(2) (3)(4) (5)(6)	51	121265 Handle
	12	152668 Gear set		51	173725 Handle AVR M14/L12
	13	113256 Nut	(1)(2) (3)(4) (5)(6)	52	113244 Spiral spring
	14	174007 Bush		60*	177368 Bearing bed set
	15	174021 Spring	(1)(2) (3)(4) (5)(6)	60**	142602 Bearing bed set
	16	174008 Pin		60*	158723 Bearing bed set HD
	17	330344 O-ring 6X1.5B NBR70	(1)(2) (3)(4) (5)(6)	60**	142273 Bearing bed set HD
	18	330352 O-ring 80X2B	61	154790	Spring
	19	360246 Screw M5x16	62	177337	Bush
(1)(2) (3)(4) (5)(6)	20	174006 Button	63	177366	Button
	20	175915 Button	64	177338	Lock lever
	21	174020 Protective washer	65	361201	Screw M5x30-8,8okc
	22	330473 Circlip A40-1D	66	177335	Spring
	23	330124 Bearing 6203-2RS	67	330331	O-ring 2-10x1,5-2
	24	177333 Body	68	330704	O-ring 5x1,5 NBR 70
	25	174005 Brush holder cover	(2)(4) (5)(6)	70**	142063 Circlip M
	26	174004 Diffuser	(1)(3) (5)	201	141226 Operating instruction
	27	177406 Stator set	(2)(6) (4)	201	141234 Operating instruction
	28	177405 Armature set		201	156447 Operating instruction
	29	190020 Brush holder set		202	174349 Tool case
	30	153014 Brush		204	141745 Grease 8 - 1,00 kg.
	31	153015 Brush with a switch			
	32	164934 Rubber bush			
	33	361360 Screw K 4X9.5 TORX 20			
	34	361428 Screw 3,9X60			
	35	154350 Fan			
	36	151648 Protective washer			
	37	331149 Bearing 608-2RS-P63 LDS18SpA			
(1)(3)(5) (2)(4)(6) (1)(2)(4) (5)(6)	38	174002 Handle			
	38	156419 Casing handle set AVS			
	39	170669 Switch PS16E02			

Note: \*- till 01.11.2013; \*\*- from 01.11.2013

(1) - only for MB 2200P c 01.02.2010; (2) - only for MB 2200PA;  
 (3) - only for MB 2200 c 01.02.2010; (4) - only for MB 2200PA/AVR  
 (5) - only for MB 2200P HD; (6) - only for MB 2200PA HD

**MB 2200P (from 01.02.2010)  
 MB 2200PA  
 MB 2200 (from 01.02.2010)  
 MB 2200PA AVR  
 MB 2200P HD  
 MB 2200PA HD**

