

PROFESSIONAL, HD PROFESSIONAL
MBA 2200P (from 01.02.2010) - 178761; MBA 2200PA - 156424; MBA 2200 (from 01.02.2010) - 178760
MBA 2200PA/AVR - 156424; MBA 2200P HD - 158765; MBA 2200PA HD - 158773

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
(1)(2)	1	178878 Gear box	(3)	39	170668 Switch PS16E01
(3)(4)			40	361328	Screw K4x18 TORX 20
(5)(6)	1	158701 Gear box HD	41	151671	Cord clamp
	2	330125 Bearing HK 1212	42	361360	Screw K 4X9.5 TORX 20
	3	330944 Bearing 6300 2RSL P63 LDS18SpA	43	361371	Screw K5X40(D10) TORX 20
	4	153341 Gasket	44	120724	Cord protector
	5	173936 Inner Flange	(1)(2)	45	152574 Cord with a plug
	6	173934 Circlip	(3)(4)		
	7	174022 Spindle	(5)(6)	45	158695 Cord with a plug euro plug RAL 3020
	8	173935 Rubber bush	46	361369	Screw A-K 5x25 TORX 20
(1)(2)	9*	177360 Bearing bed	47	121837	Back up disc washer
(3)(4)			48	121838	Locking nut
(1)(2)	9**	142598 Bearing bed	(1)(2)	49	178777 Guard Φ230 T20
(3)(4)			(3)(4)		
(5)(6)	9*	158713 Bearing bed HD	(5)(6)	49	158855 Guard Φ230 T20/HD
(5)(6)	9**	142270 Bearing bed HD	50	154269	Special spanner 240
	10	117504 Spacer washer	(1)(2)	51	121265 Handle
	11	117505 Spacer washer	(3)(6)		
	12	152666 Gear set	(4)(5)	51	173725 Handle AVR M14/L12
	13	113256 Nut	52	113244	Spiral spring
	14	174007 Bush	(1)(2)	60*	177368 Bearing bed set
	15	174021 Spring	(3)(4)		
	16	174008 Pin	(1)(2)	60**	142602 Bearing bed set
	17	330344 O-ring 6X1.5B NBR70	(3)(4)		
	18	330352 O-ring 80X2B	(5)(6)	60*	158723 Bearing bed set HD
	19	360246 Screw M5x16	(5)(6)	60**	142273 Bearing bed set HD
(1)(2)	20	174006 Button	61	154790	Spring
(3)(4)			62	177337	Bush
(5)(6)	20	175915 Button	63	177366	Button
	21	174020 Protective washer	64	177338	Lock lever
	22	330473 Circlip A40-1D	65	361201	Screw M5x30-8,8okc
	23	330124 Bearing 6203-2RS	66	177335	Spring
	24	177333 Body	67	330331	O-ring 2-10x1,5-2
	25	174005 Brush holder cover	68	330704	O-ring 5x1,5 NBR 70
	26	174004 Diffuser	(2)(4)	70**	142063 Circlip M
	27	177406 Stator set	(5)(6)		
	28	177405 Armature set	(1)(3)(5)	201	141226 Operating instruction
	29	190020 Brush holder set	(2)(6)	201	141235 Operating instruction
	30	153014 Brush	(4)	201	156447 Operating instruction
	31	153015 Brush with a switch	(5)	202	141215 Packaging
	32	164934 Rubber bush	(6)	202	174349 Tool case
	33	361360 Screw K 4X9,5 TORX 20	204	141745	Grease 8 - 1,00 kg.
	34	361428 Screw 3,9X60			
	35	154350 Fan			
	36	151648 Protective washer			
	37	331149 Bearing 608-2RS-P63 LDS18SpA			
(1)(3)(5)	38	174002 Handle			
(2)(4)(6)	38	156419 Casing handle set AVS			
(1)(2)(4)	39	170669 Switch PS16E02			
(5)(6)					

Note:

(1) - only for MBA 2200P c 01.02.2010; (2) - only for MBA 2200PA;
 (3) - only for MBA 2200 c 01.02.2010; (4) - only for MBA 2200PA/AVR
 (5) - only for MBA 2200P HD; (6) - only for MBA 2200PA HD
 * - till 01.11.2013; ** - from 01.11.2013

MBA 2200P (from 01.02.2010)
MBA 2200PA
MBA 2200 (from 01.02.2010)
MBA 2200PA AVR
MBA 2200P HD
MBA 2200PA HD

