

MB 2600P/AVR - 176312; MB 2600P - 176312; MBA 2600P/AVR - 176313; MBA 2600P - 176313

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
	1	178878 Gear box		32	164934 Rubber bush
	2	330125 Bearing HK 1212		33	361360 Screw K 4X9.5 TORX 20
	3	330944 Bearing 6300 2RSL P63 LDS18SpA		34	361433 Screw 3,9X80
	4	153341 Gasket		35	154350 Fan
	5	173936 Inner Flange		36	151648 Protective washer
	6	173934 Circlip		37	331149 Bearing 608-2RS-P63 LDS18SpA
	7	174022 Spindle		38	174002 Handle
	8	173935 Rubber bush		39	170669 Switch PS16E02
	9	174012 Bearing bed		40	361328 Screw K4x18 TORX 20
	10	117504 Spacer washer		41	151671 Cord clamp
	11	117505 Spacer washer		42	361360 Screw K 4X9.5 TORX 20
(1)(2)	12	152668 Gear set		43	361371 Screw K5X40(D10) TORX 20
(3)(4)	12	152666 Gear set		44	120724 Cord protector
	13	113256 Nut		45	152574 Cord with a plug
	14	174007 Bush		46	361369 Screw A-K 5x25 TORX 20
	15	174021 Spring		47	121837 Back up disc washer
	16	174008 Pin		48	121838 Locking nut
	17	330344 O-ring 6X1.5B NBR70	(1)(2)	49	151276 Disk guard 180E
	18	330352 O-ring 80X2B	(3)(4)	49	151268 Disk guard 230E
	19	360246 Screw M5x16		50	154269 Special spanner 240
	20	174006 Button	(1)(3)	51	173725 Handle AVR M14/L12
	21	174020 Protective washer	(2)(4)	51	121265 Handle
	22	330473 Circlip A40-1D		52	113244 Spiral spring
	23	330124 Bearing 6203-2RS	60	174025 Bearing bed set	
	24	174000 Body	(1)(3)	201	176244 Operating instruction
	25	174005 Brush holder cover	(2)(4)	201	177979 Operating instruction
	26	174004 Diffuser		202	174349 Tool case
	27	176452 Stator set		204	141745 Grease 8 - 1,00 kg.
	28	175040 Armature set			
	29	190020 Brush holder set			
	30	153014 Brush			
	31	153015 Brush with a switch			

Note:  
 (1) - only for MB 2600P/AVR; (2) - only for MB 2600P;  
 (3) - only for MBA 2600P/AVR; (4) - only for MBA 2600P

MB 2600P AVR  
 MB 2600P  
 MBA 2600P AVR  
 MBA 2600P

