

PROFESSIONAL
MBS 876 - 180002; MBS 876E - 180041

Pos. No.	Ref. No.	Description	Pos. No.	Ref. No.	Description
1	182544	Screw ST4.2X16	37	180267	Cable
3	180249	Front soft grip	38	180268	Cable sleeve
4	180250	Soft grip	39	182562	Screw ST4.2X16
5	180251	Rear wheel	40	182563	Cord set clamp plate
6	182546	Rubber sleeve	41	182564	Dust bag
8	182548	Screw ST4.2X35	42	182565	Middle enclosure
9	180252	Clamp Device	44	182566	Spring
10	180253	Spring	45	180270	Baffle insert block
11	180254	Lever	46	182567	Ring
12	182549	Washer	47	182568	Washer
13	180255	Support	48	180271	Adjustable knob
14	182550	Needle Bearing	49	182569	Bearing Plate
15	180256	Front wheel	50	180272	Stator
16	180257	Pin	51	182570	Screw ST4.2X60
17	180258	Cover board	52	180273	Baffle
18	182551	Rivet	53	180274	Rubber cover
19	180259	Aluminum bracket assembly	54	180275	Armature set
20	182552	Bearing 626	55	182571	Bearing 608
21	180260	Gear	56	182572	Small belt wheel
22	182553	Pin	57	182573	Screw ST4.2X16
23	180261	Shaft	58	182574	Screw ST2.9X10
24	182554	Washer	59	182575	Screw ST4.2X13
25	182555	Retainer ring	61	180277	Belt cover board
26	182556	Washer	62	180278	Belt wheel
27	182557	Locating Ring	63	182576	Washer
28	182558	Hole ring	64	182577	Bearing 627
29	182559	Bearing Plate	65	180279	Spring gear shaft
30	180262	Brush Holder	66	182578	Screw ST4.2X65
31	180263	Carbon brush	67	180280	Left enclosure
32	182560	Brush holder clamp plate	68	180281	Driving Belt
(1) 34	180264	Right enclosure MBS 876	(2) 70	181713	Variable Speed Control MBS 876E
(2) 34	181711	Right enclosure with Electronic MBS 876E	204	179860	Grease 2 - 1,00 kg.
35	180265	Capacitor			
36	180266	Switch			

Note:
 (1) - only for MBS 876; (2) - only for MBS 876E

MBS 876
MBS 876E

