

| POS. No. | Ref.No. | Description              | POS. No. | Ref.No. | Description             |
|----------|---------|--------------------------|----------|---------|-------------------------|
| 1        | 181801  | Chuck screw              | 18       | 181818  | Torque spring           |
| 2        | 181802  | Chuck                    | 19       | 181819  | Bit bracket             |
| 3        | 181803  | Torque setting ring      | 21       | 181842  | Top of battery pack     |
| 4        | 181837  | Gear box one speed       | 22       | 181822  | Top insulation          |
| 5        | 181838  | Motor cover              | 23       | 181823  | Battery power connector |
| 6        | 181839  | Motor                    | 24       | 181824  | Battery cell            |
| 7        | 181807  | Interior wires           | 25       | 181825  | Bottom insulation       |
| 8        | 181808  | Power indicator assembly | 26       | 181826  | Battery pack button     |
| 9        | 181809  | Power indicator cover    | 27       | 181827  | Bottom spring           |
| 10       | 181810  | Switch                   | 28       | 181843  | Battery body            |
| 11       | 181811  | Body power connector     | 29       | 181829  | Screws                  |
| 12       | 181812  | Light pcb /led/          | 30       | 181798  | Battery set BR 15E      |
| 13       | 181813  | Light cover              | 30       | 182916  | Battery set BR 15E 2Ah  |
| 14       | 181840  | Left housing             | 31       | 181799  | Charger EU BR 15E       |
| 15       | 184831  | Gears selecting button   | 31       | 181800  | Charger GB BR 15E       |
| 16       | 181841  | Right housing            | 31       | 182703  | Charger EU              |
| 17       | 181817  | Steering block           | 204      | 179860  | Grease 2 - 1,00 kg.     |

