

POS. No.	Ref. No.	Description	POS. No.	Ref. No.	Description
1	124612	Chuck 16M	39	170033	Slide
1	118984	Chuck B13L	40	119814	Fixing bit
2	890311	Circlip J32x1,2	41	130580	Spring
3	124075	Spindle set	42	116831	Plate
4	330266	Gasket R15x32x7UEN TREC00150	43	116884	Pin
5	124077	Spindle	44	151972	Armature set
6	330014	Bearing 6002-2Z	45	130581	Bush
7	119185	Hammer bush	46	330942	Bearing 609 2RSL P63 LDS18SpA
8	140005	Washer	47	152579	Fan
9	119022	Spring	48	330582	Bearing 6262ZP6E LDS18 SKF
10	330074	Pellet 5-200	49	129087	Elastic sleeve
11	330267	Needle for bearing B3x19.8 G	50	151969	Diffuser
12	151960	Gear box set	51	151947	Claming pin
13	119187	Hammer bush	52	151982	Stator set
14	115958	Spacer washer	53	152856	Capacitor
15	151953	Gear box	54	173348	Switch Defond DGQ 1106HOHBR
16	361409	Screw K5X45 TORX 20	55	152837	Body
17	330073	Pellet 3,5-200	57	153323	Choke 7uH,6A,250V
18	130580	Spring	58	153057	Brush with a switch
19	330339	O-ring 2-11x2-2	59	153056	Brush
20	170022	Gear switch	60	151971	Brush holder set
21	151959	Switching plate	61	254364	Spiral spring
22	122440	Axle	62	151966	Casing handle set
23	122444	Locking panel	63	154354	Insert
24	115865	Pin	64	361425	Screw K4X16 TORX 20
25	117848	Spacer washer	65	361360	Screw K 4X9.5 TORX 20
26	122427	Spindle gear I	66	256500	Cord clamp
27	124078	Clutch set	67	114292	Key holder
28	122434	Spindle gear II	68	206687	Cord protector
29	122435	Spacer washer	69	116549	Cord with a plug
30	330233	Bearing HK0810RS	70	360777	Screw M6LHx30
31	330119	Bearing HK0609	70	360582	Screw M6LHX30-8.8
32	140033	Spacer washer	71	121152	Handle set
33	122436	Gear shaft set	72	121134	Depth gauge
34	122437	Gear shaft	73	121306	Butterfly screw set
35	122438	Spindle gear II for Gear shaft	74	271221	Plate
36	122439	Large intermediate gear	75	114032	Nut M6
37	330017	Bearing 626	76	121133	Handle
38	151955	Bearing shield			

