

POS. No.	Ref.No.	Description	POS. No.	Ref.No.	Description
1	184419	Lock piece	40	184436	Screw M6x14
2	184418	Lock piece spring	41	184433	Fender ring φ10
3	184417	Screw M4x14	42	184434	Wide nut M6
4	184415	Laser holder	43	184435	Depth bevel scale housing
5	184408	Washer φ4	44	184438	Washer M5x14x2
6	184406	Screw M4x10	45	184437	Nut M5
7	184413	Screw M4x12	46	184439	Rivet φ 6x7
8	184412	Laser	48	184390	Check screw
9	184411	Nut M4	49	184389	Soleplate
10	184414	Locating circlip	50	184454	Screw ST 4.2x16
11	184410	Site block circular	51	184467	Screw M5x28
12	184416	Frame	52	184465	Left handle
13	184422	Bearing 8x14x8	53	184471	Power cord and Plug UK BS4343 16A/110-130V
14	184423	Oil-retaining bearing	54	184473	Transformer
15	184424	Wave washer	55	184463	Laser knob
16	184425	Gear	57	184472	Switch
17	184426	Front cover	58	184461	Capacitance
18	184409	Screw M6x16	59	184459	Screw ST 4.2x14
19	184428	Screw ST 4.8x35	60	184457	Cable Clamp
20	184429	Steele sleeve	61	184458	Cable sleeve
21	184430	Bearing 6001-2Z	62	184456	Right Handle
22	184404	Out spindle	63	184455	Nut M5
23	184407	Anchorage	64	184453	Back cover
24	184405	Half circle key	65	184450	Brush holder
25	184431	Spring	66	184470	Brush 110V
26	184403	Safety cover	67	184452	Insert piece
27	184402	Plate	68	184448	Housing
28	184401	Screw M4x8	69	184469	Stator set
29	184400	Inner plate	70	184446	Air baffle plate
30	184398	Outer plate	71	184445	Screw ST 4.8x65
31	184397	Screw	72	184444	Bearing Sleeve
32	184421	Wrench	73	184443	Bearing 607-2Z
33	184396	Head shell cover	74	184468	ARMATURE ASS'Y
34	184394	Spring pin φ6	75	184441	Bearing 6000-2Z
35	184393	Nut M6	76	184440	Screw M5x12
36	184391	Angle traveling rest M6	80	184388	Parallel guide
37	184392	Mat piece φ6	81	184587	HEX KEY
38	184395	Screw M6x12	82	184399	Saw blade
39	184432	Wrench			

