


POS. No.	Ref. No.	Description	POS. No.	Ref. No.	Description
1	180977	Cap, bearing	47	181023	Filter
2	180978	Bearing 9DB-620101	48	181024	Housing Ass'y
3	180979	Crank rod ass'y	49	181025	Holder, cable
4	180980	Piston	50	181026	Lever, choke
5	180981	Ring, piston	51	181027	Holder, choke lever
6	180982	Roller, piston	52	181028	Spring
7	180983	Pin, piston	53	181029	Connector
8	180984	Ring 9CA-10.3	54	181030	Oil pipe
9	180985	Case, crank	55	181031	Pump ass'y
10	180986	Spark plug	56	181032	Spring washer
11	180987	Cylinder	57	181033	Baffle
12	180988	Isolator, rubber	58	181034	Baffle
13	180989	Spacer	59	181035	Muffler ass'y
14	180990	Screw 9STDB-05-60	60	181036	Screw 9SXDB-06-70
15	180991	Isolator, carburetor	61	181037	Cable, throttle
16	180992	Spring washer	62	181038	Fuel pipe
17	180993	Screw 9SACB-06-25	63	181039	WOODRUFF KEY
18	180994	Spacer	64	181040	Mesh
19	180995	Carburetor	65	181041	Filter, air
20	180996	Air filter, ass'y	66	181042	Spiked bumper
21	180997	Nut 9NHZ-05	67	181043	Screw 9SKKY8-16-1
22	180998	Screw 9SGKBY10/14-0.625	68	181044	Screw 9SKKY8/16-1.4
23	180999	Handle, left	69	181045	Shroud
24	181000	Trigger, throttle	70	181046	Screw 9SKKY05-18
25	181001	Trigger, release	71	181047	Nut 9NAB-05
26	181002	Spring	72	181048	Felt
27	181003	Screw 9SKKY10/14-0.68	73	181049	Worm
28	181004	Rubber	74	181050	Cap, anti-dust
29	181005	Handle, rear	75	181051	Screw 6SDABB04-08
30	181006	Switch	76	181052	Screw 9SKKY8/16-0.5
31	181007	Washer 9WFB-05-21	77	181053	Drum ass'y
32	181008	Screw 9014-310208	78	181054	Clutch ass'y
33	181009	Handle, front	79	181055	Cap, anti-dust
34	181010	Starter housing ass'y	80	181056	Nut 9NHC-09
35	181011	Nut 9NAB-5/16-24	81	181057	Brake kit ass'y
36	181012	Flywheel	82	181058	Nut 9NAZ-5/16-18
37	181013	Screw 9SGEB-05-20	83	181059	BAR 16"(OREGON)
38	181014	Wire ass'y	84	181061	Chain16"(OREGON BLACK)
39	181015	Ignition ass'y	85	181062	Washer 9WFB-4.5-13
40	181016	Conductive plate	86	181060	Screw 9SKKBB-04-10
41	181017	Oil cap ass'y	87	180971	Wrench
42	181018	Spring ass'y	88	180972	Bar cover
43	181019	Primer	89	180965	Engine Oil bottle - 95ml
44	181020	Fuel cap ass'y	90	180966	Bar groove cleaner
45	181021	Spring	91	180967	Lube GUN 31187-A
46	181022	Screw 9SFAB-06-55			



181063

181064