

| POS. No. | Ref.No. | Description | POS. No. | Ref.No. | Description |
|----------|---------|-----------------------------|----------|---------|------------------------|
| 1 | 184743 | SCREW 4x20 | 19 | 184727 | LOCKS CLASP |
| 2 | 184710 | SWITCH | 20 | 184771 | BACK BARREL FEET LEFT |
| 3 | 184711 | COVER | 21 | 184774 | SCREW 4x12 |
| 4 | 184779 | INNER AIR TUBE | 22 | 184777 | CASTORS |
| 5 | 184749 | SCREW 4x20 | 23 | 184731 | HANDLE |
| 6 | 184750 | SCREW 4x14 | 24 | 184780 | SEAL RING |
| 7 | 184751 | WIRE FIXING | 25 | 184772 | BACK BARREL FEET RIGHT |
| 8 | 184752 | MOTOR TOP COVER | 26 | 184753 | SEAL RING |
| 9 | 184717 | MOTOR | 27 | 184734 | SPONGE FILTER |
| 10 | 184755 | MOTOR BELOW SEAL RING | 31 | 184773 | FRONT BARREL FEET |
| 11 | 184756 | AIR INLET GRID | 32 | 184775 | BIG BACK WHEELS |
| 12 | 184720 | MOTOR BASE COVER | 33 | 184776 | BIG WHEELS CAP |
| 13 | 184758 | INNER PART OF SUCTION MOUTH | 34 | 184741 | CAPACITOR |
| 14 | 184759 | MUFFLE | 35 | 184785 | CABLE |
| 15 | 184723 | CONNECTER | 39 | 184781 | FLOATER CUP |
| 16 | 184724 | TANK | 40 | 184782 | Seal (For Lower Cover) |
| 17 | 184725 | SHAFT 1 | 41 | 184783 | SCREW 4x14 |
| 18 | 184726 | SHAFT 2 | 44 | 191471 | Filter locking cap |

